

fully assembled DLP trunking 50 x 80


trunking and fittings

Cat.Nos for 50 x 80 trunking



Selection chart (p. 825)
Wiring capacity chart (p. 839)

| Pack | Cat.Nos | Fully assembled trunking |
|------|-----------------------|---|
| 20 | 104 62 ⁽¹⁾ | Trunking without partition Supplied with: – one 50 x 80 mm body – one flexible cover 65 mm wide Fits onto the whole trunking including in internal and external angles Installation: can be used with ranges: Mosaic, Arteur or Lexic Length 2 m |
| 24 | 105 82 ⁽¹⁾ | Partition Separation partition Length 2 m |
| 20 | 106 91 | Joints Body joint For aligning bases during installation |
| 20 | 106 92 | Body joint, attached with adhesive (fit at the end of installation) |
| 10 | 108 01 | Cover joint for 65 mm cover |



| Pack | Cat.Nos | Junctions |
|------|---------|--|
| 5 | 107 35 | Flat junction For tap-off to a 80 mm wide branch |
| 5 | 107 63 | Angled junction For tap-off in an internal angle to 35 x 80, 35 x 105, 50 x 80, 50 x 105 For use with internal angles Cat.No 106 02 |

| Pack | Cat.Nos | Accessories |
|------|---------|----------------|
| 50 | 106 81 | Clip |
| 100 | 308 81 | Base for clamp |

Installation accessories (p. 836-838)

| Pack | Cat.Nos | Angles and end cap |
|------|---------|--|
| 10 | 106 02 | Internal and external bends Include the 2 components for the top and bottom of the trunking on which the flexible cover is fitted Changeable internal bend, from 85° to 95° for 50 x 80/50 x 105/50 x 150 and 50 x 195 mm trunkings |
| 10 | 106 22 | Changeable external bend, from 60° to 120° for 50 x 80/50 x 105/50 x 150 and 50 x 195 mm trunkings |
| 10 | 107 67 | Flat angle 90° flat angle |
| 10 | 107 22 | End cap Left or right end cap |